
stella washlounge

#2423 #2424 STELLA (XL WHITE BASIN) STELLA (XL BLACK BASIN)





IMPORTANT PLEASE READ THESE SAFETY INSTRUCTIONS

GENERAL SAFETY

- Read carefully and keep these instructions in a safe place.
- Use this product only for its intended function and do not use attachments not recommended by the manufacturer.
- 3. Do not use outdoors.

PLUMBING

1. This unit must be plumbed by a licensed plumber.



IMPORTANT

ALL PLUMBING MUST BE COMPLETED BY A LICENSED PLUMBER




IMPORTANT


DO NOT ALLOW CHILDREN AROUND THE WASHLOUNGE WHEN IN USE


GET STARTED


STELLA

Wash Lounge











POSITIONING



If washing from behind, allow a minimum of 400mm of space behind your washlounge to provide room for access.



If washing from side add 400mm (15.75"). All measurements in mm (inches).

BEFORE INSTALLING YOU SHOULD CONSIDER THE FOLLOWING

- Allow for the necessary room around the unit for free movement.
- If installing against a wall, a minimum distance of 80mm (3.15") between wall and bottom back of basin is required to allow free movement of basin.
- If plumbing location is in wall (see Diagram A).
 For neatness of finish it is preferable to bring water and waste into the wash lounge in the same hole.
- If plumbing location is on floor (see Diagram A), place wash lounge over.

PLUMBING ACCESS OPTIONS

Determine the best way to connect plumbing.

OPTION A: FROM WALL TO BASIN STAND


From behind the basin stand connect $\ \ plumbing$ to the wall

OPTION B: FROM FLOOR BENEATH SEAT

From under the chair seat connect plumbing to the floor



BEFORE INSTALLATION SECURE AND BOLT DOWN






THE WASHLOUNGE MUST BE SECURED TO THE FLOOR.

Making sure your wash lounge is supported from behind, remove the back panel by unscrewing the two screws located on the left and right of the access panel. Fix to the floor through connector brackets using bolts.


INSTALLATION & ASSEMBLY: BASIN & STAND

DIAGRAM D



BASIN ASSEMBLY


- 1. Opening at back of chair
- 2. Steel frame
- 3. Bolts (supplied)
- 4. Stainless steel cover
- 5. Ceramic basin with Avitar Tilt.
- Undo bolts and remove steel frame from the opening of the back of chair.
- Flip steel frame over and re-bolt onto the inside of the chair using bolts supplied.



· Secure the stainless cover onto the steel frame.




· Remove Washer & Springs from the basin



• Install Basin into steel frame and re-intall the Washer & spring back into place and tighten.

Refer to Plumbing Diagram for Plumbing Connection

PLUMBING



PARTS

- Flick Mixer
- 2 Showerhead
- 3 Showerhose basin collar 15 Hot & cold braided hoses

13 Seal

16 Long nut

19 O-ring

17 Plastic washers

18 Metal washers

14 P trap (not supplied)

- 4 Comfortneck
- O-rina
- Foam washers 6
- 7 Plastic nut
- 8 Flat seal
- 9 Fitted flange
- 10 2 x Dyna bolts
- 11 Flexible waste pipe
- 12 Flange

the floor using 2 x Dyna bolts (supplied).

BASIN INSTALLATION

- 2. Remove washer *θ* springs from the basin
- 3. Install basin into stand and re-intall the washer & spring back into place and tighten.

TAP SET & HOSE INSTALLATION

- 4. Install Flick Mixer using O-ring, plastic and metal washers & (Long Nut) and Shower Head using the Showerhose Basin Collar, O-ring, Foam Washer & Plastic Nut as indicated.
- 5. Place Flick Mixer and Shower Head Hoses through the holes in the basin.
- 6. Connect Flexible Waste Pipe to Plug and Waste which is already installed making use of the with Flat Seal and fitted Flange.

PLUMBING CONNECTION

- 7. Connect Flexible Waste Pipe to P trap (not supplied) making use of Seal and Flange.
- 8. Connect hot and cold (1/2" connection) braided hoses to respective supplies.
- 9. Please attach Comfortneck to the basin.

ALWAYS FOLLOW THE CLEANING INSTRUCTIONS

UPHOLSTERY

- · All upholstery needs some care; good housekeeping will help to prolong the life of any upholstered products.
- · Avoid extreme temperatures. Extreme cold can make your vinyl prone to cracking, while extreme heat can cause permanent stretching.
- · Avoid exposing to direct sunlight for prolonged periods of time.
- Clean regularly (weekly) to remove body oils which cause hardening or damage
- To clean use a sponge which has been moistened in warm soapy water
- · After cleaning with a sponge, dry with a soft, clean cloth
- · Stubborn grime may require gentle scrubbing with a soft brush

Do not use:

acetone
bleach
abrasive cleaners
furniture polishes
detergent
steel wool


METAL AREAS

Wipe using regular cleaning products that are recommended for stainless steel and metals.

Do not use:

acetone
 bleach
 abrasive cleaners
 furniture polishes
 detergent
 steel wool

Damage caused by any improper treatment is not covered by the product warranty.



MAINTENANCE

A periodic inspection of all components and fasteners should be made to ensure that your washlounge is structurally intact and functioning properly.

Damaged and broken parts should be replaced and loose fasteners tightened.

All maintenance to be carried out by a suitably qualified tradesperson.

HOW TO CHANGE A SHOWERHEAD OR SHOWERHOSE

Please view our online how to videos and further troubleshooting:

https://help.comfortel.com.au/hairdressing-basins/



comfortel.com.au

PRODUCT CODE

WARRANTY PERIOD

#2423 STELLA WASHLOUNGE (WHITE BASIN) #2424 STELLA WASHLOUNGE (BLACK BASIN)

©Comfortel Furniture. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without written consent of Comfortel Furniture Pty Ltd.

NOTE YOUR PURCHASE DATE & INVOICE NUMBER FOR FUTURE REFERENCE

The information contained in this document is subject to change without notice and should not be construed as a commitment by Comfortel Furniture Pty Ltd.

Comfortel Furniture Pty Ltd. assumes no responsibility for any errors that may appear in this document nor does it make expressed or implied warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Comfortel Furniture Pty Ltd. shall not be liable for incidental or consequential damages in connection with or arising out of the use of this document and the program material.

PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE

For more information about our products and services, contact us at comfortel.com.au $\,$

TERMS AND CONDITIONS. For more information about our warranty, please refer to our website.		
PURCHASE DATE	INVOICE NUMBER	