


dusty washlounge

#2441

DUSTY (WHITE BASIN)

#2442

DUSTY (BLACK BASIN)





IMPORTANT PLEASE READ THESE SAFETY INSTRUCTIONS

GENERAL SAFETY

1. Read carefully and keep these instructions in a safe place.
2. Use this product only for its intended function and do not use attachments not recommended by the manufacturer.
3. Do not use outdoors.

PLUMBING

1. This unit must be plumbed by a licensed plumber.



IMPORTANT





ALL PLUMBING MUST BE COMPLETED BY A LICENSED PLUMBER




IMPORTANT

DO NOT ALLOW CHILDREN AROUND THE WASHLOUNGE WHEN IN USE

GET STARTED



**BEFORE INSTALLATION
SECURE AND BOLT DOWN**




THE WASHLOUNGE MUST BE SECURED TO THE FLOOR.

Making sure your wash lounge is supported, lift and remove the back seat. Secure to the floor through connector brackets using appropriate fixings (not supplied).


POSITIONING

DIAGRAM A



If washing from behind, add a minimum of 400mm of space behind your wash lounge to provide room for access.

DIAGRAM B



If washing from side add 400mm between each basin. All measurements in mm.

BEFORE INSTALLING YOU SHOULD CONSIDER THE FOLLOWING

- Allow for the necessary room around the unit for free movement.
- If installing against a wall, a minimum distance of 80mm between wall and bottom back of basin is required to allow free movement of basin.
- If plumbing location is in wall (see Diagram A). For neatness of finish it is preferable to bring water and waste into the washlounge in the same hole.
- If plumbing location is on floor (see Diagram A), place washlounge over.

PLUMBING ACCESS OPTIONS

Determine the best way to connect plumbing.

OPTION A: FROM WALL TO BASIN STAND

From behind the basin stand connect plumbing to the wall

OPTION B: FROM FLOOR BENEATH SEAT

From under the chair seat connect plumbing to the floor




IMPORTANT

ALL PLUMBING MUST BE COMPLETED BY A LICENSED PLUMBER

PLUMBING

DIAGRAM C



BASIN ASSEMBLY

- | | |
|---------------------------|-----------------------------|
| 1 Flick Mixer | 13 Seal |
| 2 Showerhead | 14 P trap (not supplied) |
| 3 Showerhose basin collar | 15 Hot & cold braided hoses |
| 4 Comfortneck | 16 Long nut |
| 5 O-ring | 17 Plastic washers |
| 6 Foam washers | 18 Metal washers |
| 7 Plastic nut | 19 O-ring |
| 8 Flat seal | |
| 9 Fitted flange | |
| 10 Connector Bracket | |
| 11 Flexible waste pipe | |
| 12 Flange | |

WASHLOUNGE ASSEMBLY

1. Washlounge **MUST** be secured to the floor. Secure to the floor using appropriate fixings (not supplied).

BASIN ASSEMBLY


2. Install Flick Mixer using O-ring, plastic and metal washers & (Long Nut) and Shower Head using the Showerhose Basin Collar, O-ring, Foam Washer & Plastic Nut as indicated.
3. Place Flick Mixer and Shower Head Hoses through the holes in the basin.
4. Connect Flexible Waste Pipe to Plug and Waste which is already installed making use of the with Flat Seal and fitted Flange.

PLUMBING CONNECTION

5. Connect Flexible Waste Pipe to P trap (not supplied) making use of Seal and Flange.
6. Connect hot and cold (½" connection) braided hoses to respective supplies.
7. Please attach Comfortneck to the basin.

INSTALLATION & ASSEMBLY: BASIN

DIAGRAM D



BASIN ASSEMBLY

1. Stainless steel cover
2. Bolts (supplied)
3. Ceramic basin

INSTALLING BASIN

- Attach Stainless steel cover with the bolts to the back of the chair.

IMPORTANT

PLEASE MAKE SURE THERE IS SUPPORT AT THE BACK OF THE WASH LOUNGE WHERE THE WASH BASINS ARE LOCATED, AS ONCE THE SEAT CUSHION IS REMOVED - THE UNIT COULD TILT BACKWARDS.



CLEANING

ALWAYS FOLLOW THE CLEANING INSTRUCTIONS

UPHOLSTERY

All upholstery needs some care; good housekeeping will help to prolong the life of any upholstered products. Avoid extreme temperatures. Extreme cold can make your vinyl prone to cracking, while extreme heat can cause permanent stretching. Avoid exposing your products to direct sunlight for prolonged periods of time.

ALWAYS FOLLOW THE CLEANING INSTRUCTIONS

- Wipe with a clean colourfast cloth dampened with mild alkaline free soap and luke warm water. Do not wet excessively.
- Remove all traces of any cleaning product by wiping with fresh water and a clean cloth.
- Dry with a soft, clean cloth.
- Stubborn grime may require gentle scrubbing with a soft brush.

Do not use:

- hot or boiling water
- hydrocarbons including alcohol
- acetone
- furniture polishes
- bleach
- concentrated detergents
- abrasive powder or paste cleaners
- steel wool
- silicon or petroleum-based cleaners
- solvent based or abrasive cleaning agents

METAL AREAS

Wipe using regular cleaning products that are recommended for stainless steel and metals.

Do not use:

- acetone
- bleach
- abrasive cleaners
- furniture polishes
- detergent
- steel wool

Damage caused by any improper treatment is not covered by the product warranty.

MAINTENANCE

A periodic inspection of all components and fasteners should be made to ensure that your washlounge is structurally intact and functioning properly.

Damaged and broken parts should be replaced and loose fasteners tightened.

All maintenance to be carried out by a suitably qualified tradesperson.

HOW TO CHANGE A SHOWERHEAD or SHOWERHOSE

Please view our online video on how to change a showerhead or showerhose: help.comfortel.com.au

comfortel

help.comfortel.com.au

PRODUCT CODE

#2441 DUSTY WASHLOUNGE (WHITE BASIN)

#2442 DUSTY WASHLOUNGE (BLACK BASIN)

©Comfortel Furniture. All rights are reserved. No part of this document may be photocopied, reproduced or translated to another language without written consent of Comfortel Furniture Pty Ltd.

The information contained in this document is subject to change without notice and should not be construed as a commitment by Comfortel Furniture Pty Ltd.

Comfortel Furniture Pty Ltd. assumes no responsibility for any errors that may appear in this document nor does it make expressed or implied warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Comfortel Furniture Pty Ltd. shall not be liable for incidental or consequential damages in connection with or arising out of the use of this document and the program material.

PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE

For more information about our products and services, contact us at comfortel.com.au

PURCHASE DATE

INVOICE NUMBER

NOTE YOUR PURCHASE DATE & INVOICE NUMBER FOR FUTURE REFERENCE