


moval salon trolley



IMPORTANT PLEASE READ THESE SAFETY INSTRUCTIONS

GENERAL SAFETY

1. Read carefully & keep these instructions in a safe place.
2. Use this product only for its intended function and do not use attachments not recommended by the manufacturer.
3. Suitable for dry locations ONLY.
4. Do not use outdoors or on wet surfaces.

PRECAUTIONS

1. Do not leave Mova trolley when plugged in to wall socket. Unplug from outlet when not in use. Take extra precautions when trolley is plugged in to prevent a tripping hazard.
2. Do not stretch the cable or place the cable under strain. Keep the cable away from heated surfaces. Do not close a door on the cable, or pull the cable around sharp edges or corners. Arrange the cable away from traffic areas and where it will not be stepped on or tripped over. Do not run the trolley over the cable.

ELECTRICAL APPLIANCES

1. Do not allow children to operate in this product.
2. Turn the power off and remove the plug when not in use or when cleaning.
3. Do not let the power cord get damaged in any way.
4. Do not use an extension cord with this product to prevent overloading the power board.
5. Periodically inspect the power cord for signs of damage.
6. Do not use with damaged cable or plug. If the supply cable is damaged, it must be replaced by Comfortel in order to avoid a hazard.





Water poses a serious risk even when device is switched off, do not leave device connected to power supply after use.



CAUTION: DO NOT LEAVE MOVA TROLLEY UNATTENDED WHEN PLUGGED IN TO WALL SOCKET. UNPLUG FROM OUTLET WHEN NOT IN USE. TAKE EXTRA PRECAUTIONS WHEN TROLLEY IS PLUGGED IN TO PREVENT A TRIPPING HAZARD.


SPECIFICATIONS

Width: 520-930mm (20.4-36.6")
Length: 360mm (14.2")
Height: 950mm (37.4")
Weight: 26kg (64lbs)



measurements in mm (inches)


WHEEL ASSEMBLY



PARTS

A	B
1 PC	4 PCS

OPERATION



OPERATING THE POWER BOARD

1. Plug hair tool/electrical device into power board.
2. Turn on Power using the On/Off Switch
3. When finished with the hair tool/electrical device, turn off Power at the end of the operation.
4. Take extra caution with power cords. Do not leave the Mova trolley unattended, to prevent tripping or getting caught on cords.
5. Unplug when not in use for extended periods and before maintenance or servicing.
5. Always turn 'OFF' the trolley powerboard before connecting or disconnecting any electrical devices.

STORING

When the Mova trolley is not in use, please turn off POWER at the end of the operation. Unplug power cord from the wall and wrap around back panel of trolley. Store away until next use.

CLEANING & MAINTENANCE

For cleaning the surfaces, wipe using a soft, damp cloth moistened with warm soapy water. Dry with clean soft cloth (never use abrasive cleaners).

Do not use:

- acetone
- furniture polishes
- bleach
- detergent
- abrasive cleaners
- steel wool

A periodic inspection of all components and fasteners should be made to ensure that your Comfortel product is structurally intact and functioning properly. Damaged and broken parts should be replaced and loose fasteners tightened. All maintenance to be carried out by a suitably qualified tradesperson.



DO NOT USE THE SIDE DRAWERS TO LIFT THE TROLLEY



DO NOT USE AN EXTENSION CORD WITH THIS PRODUCT TO PREVENT OVERLOADING THE POWER BOARD.

WARRANTY


Your Comfortel Mova Trolley will be covered for parts for 12 months from the date of purchase, subject to the terms of warranty provided by your local distributor. If you have any queries about your Comfortel Mova Trolley, call your local distributor with details of where/when you brought the Mova Trolley. Most queries can be solved by your local distributor.



POWERBOARD TYPE I
4-OUTLET POWERBOARD
4 USB PORTS
INPUT 230-240V ~50HZ
REGIONS:
AUSTRALIA, NEW ZEALAND, ARGENTINA
TOTAL MAX LOADING 10A, 2400W



POWERBOARD TYPE F
4-OUTLET POWERBOARD
2 USB PORTS
INPUT 230-250V ~50HZ
REGIONS:
EUROPE, RUSSIA



POWERBOARD TYPE G
6-OUTLET POWERBOARD
2 USB PORTS
INPUT 250V ~50HZ
REGIONS:
UNITED KINGDOM, IRELAND, MALTA,
MALAYSIA, SINGAPORE, UAE, SAUDI ARABIA



POWERBOARD TYPE B
6-OUTLET POWERBOARD
2 USB PORTS
INPUT 100-127V ~50HZ
REGIONS:
USA, CANADA, MEXICO, JAPAN

comfortel

help.comfortel.com.au

PROFESSIONAL USE ONLY FOR INDOOR USE IN DRY LOCATION

©Comfortel Furniture. All rights are reserved.
No part of this document may be photocopied,
reproduced or translated to another language without
written consent of Comfortel Furniture Pty Ltd.

The information contained in this document is subject to change without notice and
should not be construed as a commitment by Comfortel.

Comfortel assumes no responsibility for any errors that may appear in this document
nor does it make expressed or implied warranty of any kind with regard to this material,
including, but not limited to, the implied warranties of merchantability and fitness for a
particular purpose.

Comfortel shall not be liable for incidental or consequential damages in connection
with or arising out of the use of this document and the program material.

PLEASE RETAIN THIS INFORMATION FOR FUTURE REFERENCE.

For more information about our products and services, contact us at comfortel.com.au

PURCHASE DATE

INVOICE NUMBER

NOTE YOUR PURCHASE DATE & INVOICE NUMBER FOR FUTURE REFERENCE