
## assembly instructions

## comfortel

## salon chair footrest



## CLEANING & MAINTENANCE

· Wipe with a clean colourfast cloth dampened with mild alkaline free soap and luke warm water. Do not wet excessively. · Remove all traces of any cleaning product by wiping with fresh water and a clean cloth.

· Dry with a soft, clean cloth.

Stubborn grime may require gentle scrubbing with a soft brush.

Do not use: ·hot or boiling water ·hydrocarbons including alcohol ·acetone ·bleach ·steel wool silicon or petroleum-based cleaners

·furniture polishes ·concentrated detergents abrasive powder or paste cleaner ·solvent based or abrasive cleaning agents

A periodic inspection of all components and fasteners should be made to ensure that your salon chair is structurally intact and functioning properly

for more help, tips & solutions go to help.comfortel.com.au

©Comfortel Furniture. All rights are reserved. No part of this ument may be photocopied, reproduced or t another language without written consentof Comfortel Furniture